

Fixing droopy eyelids on your '67 – 68 Cougar A Curb exclusive tech article



OK here's the end result first because everybody loves instant gratification, right?

First of all you need to make a trip to Lowe's. I have heard that there are Lowe's stores in most states and major communities. If you don't have a Lowe's then a Home Depot, Tractor Supply Co. or hardware store should have all the necessary parts on the list below with the exception of the sun visor tip rubber bumpers which can be bought from any of the Cougar part suppliers found at <http://www.cougarclub.org> in the links / vendors section.

Tools you will need for this job:

- * Phillips screwdriver
- * Hack Saw
- * File

Parts needed for this project

Qty	Description	Supplier / Manufacturer
1 pkg	Oval head screws 8-32 X 2 SS (5 in pkg)	Hillman
2 ea	¼ (ID) X 3/8 (OD) X ½ (Long) Steel Spacer	Hillman
4 ea	¼ X 5/16 X ¾ Sleeve Bushings Bronze	Hillman
2 ea	¼ X 3/8 X ¾ Steel Spacer	Hillman
4 ea	Rubber sun visor tips	Cougar part dealer

Cut the two ¾” steel spacers down to ¼” length. If your hardware store has ¼” long spacers that would be appropriate, buy those instead and you won’t have to use a hacksaw for this job. Use the file to deburr all cut edges.



Hillman prepackages the parts as shown. The rubber sun visor tip is at top left.

From the headlight adjuster door remove the lower two screws. At the inboard position of each headlight door use:

QTY	Description	Manufacturer
1	Oval head screws 8-32 X 2 SS (5 in pkg)	Hillman
1	¼ (ID) X 3/8 (OD) X ½ (Long) Steel Spacer	Hillman
1	¼ X 5/16 X ¾ Sleeve Bushings Bronze	Hillman
1	Rubber sun visor tips	Cougar part dealer



Here is a picture showing the finished installation at the inboard lower screw of the headlight adjuster door.

Use the remaining parts on the outboard headlight door.



Picture showing the steel spacer cut down to ¼" height, the bronze bushing and the rubber sun visor tip. The screw is inside and cannot be seen.